

The Anatomy of Your Device

- 1. Cartridge Chamber:**
Magnetically secures your cartridge.
- 2. LED Lights:**
Indicate the activation status of Series 3.
- 3. Activation Button:**
Controls vapor production.
- 4. LED Perimeter:**
Glows different colors to indicate the temperature of Series 3.
- 5. Metal Charge Port:**
Connects to the magnetic head of the USB charging cord.

Your 3-in-1 Vaporizer

Series 3 is capable of vaporizing three mediums: e-liquid, loose leaf and wax*; each with its own specifically designed, compatible cartridge. Your Series 3 Kit comes with one e-liquid cartridge. Loose leaf and wax* cartridges may be purchased separately.




E-Liquid



Loose Leaf



Wax



V2® PRO

V2® PRO

SERIES 3

Genuine. Satisfaction.™

USER MANUAL

Visit V2.com to:

- Download your free E-Liquid Quality Assurance Report.
- Reference our complete User Manual.
- View a detailed list of all e-liquid ingredients.
- Access the V2® Store Locator to find V2® retail locations near you.

Should you have any questions regarding our Limited Warranty or need to request a replacement on an electrical component, please contact our Customer Service Department, toll-free at:

1-877-37-VAPOR (1-877-378-2767)



Initiating Your Device

1. Remove Series 3 components from their packaging and charge your device, using the included USB Charger.



2. Unscrew the mouthpiece of your cartridge and fill the chamber.



3. Align the small circle on the cartridge with the notch on your device and slide the cartridge into the cartridge chamber.



4. Unlock your device for use by pressing the activation button three times within two seconds.

5. Press the activation button and discover the satisfaction of Series 3.

Get Charged

Series 3 arrives with a partial charge, so make sure you completely charge it before its initiation. Plug the included charger into a USB port and connect the magnetic head to the metal port on the end of the device. The white LEDs under the activation button and along the perimeter will flash, indicating that Series 3 is charging. You'll see the perimeter LED lights intermittently glow red; turning green when Series 3 is fully charged.

Series 3 will need to be recharged when the white LED lights begin a set of double blinks that dim off gradually. But this won't put your experience on pause – Series 3 is designed for use while charging. Connect Series 3 to the USB charger and continue normal use.

Locking and Unlocking Series 3

Like your cell phone, Series 3 has a lock feature to prevent accidental activation. Push the activation button three times within two seconds and you'll see the red LED perimeter flash three times. This will lock Series 3 and render it unresponsive to accidental actions when not in use. To unlock, push the activation button three times within two seconds. The white LED lights will flash three times, indicating Series 3 is ready to use.

Series 3 Compatible Cartridges

Series 3 is able to vaporize three different types of ingredients: e-liquid, wax* and loose leaf. V2 Pro offers three types of compatible vaporizer cartridges, with each specially designed for use with a specific form of ingredient. The intelligent mechanics of Series 3 allow it to automatically recognize each type of cartridge and perform accordingly.

The cartridge included with Series 3 is an e-liquid cartridge.

Cartridge Use

E-Liquid Cartridge

1. Unscrew the mouthpiece from the cartridge and drip e-liquid into the clear chamber.
 - Hold the cartridge at a slight angle when filling it to prevent e-liquid from entering the hollow center cylinder.
 - Do not fill beyond the full line.
2. Replace the mouthpiece and insert the cartridge into the Series 3 cartridge chamber.
3. Make sure that Series 3 is unlocked.
4. Press the activation button and begin puffing.
 - If the activation button is pressed for ten seconds or longer while the e-liquid cartridge is in use, the white LED lights will flash five times before Series 3 automatically cuts off. This eliminates the potential for accidental activation.

Loose Leaf Cartridge

1. Remove the mouthpiece from the cartridge and add loose leaf to the chamber.
 - For best results, use loose leaf that is ground or shredded.
 - Be sure not to pack tightly* or beyond the white ceramic line.
2. Replace the mouthpiece and insert the cartridge into the cartridge chamber.
3. Make sure Series 3 is unlocked.

4. Press and hold the activation button for three seconds to activate the conduction heating function.
 - As Series 3 warms to optimal temperature, the LED perimeter will glow red, then yellow and finally green. When the lights are glowing green, Series 3 has reached the ideal temperature to vaporize loose leaf.
 - Series 3 takes an average of 20 to 25 seconds to reach optimal loose leaf vaporizing temperature.
 5. Once the perimeter LEDs glow green, puff freely without pressing the activation button.
 6. Pressing and holding the activation button for three seconds after Series 3 has been activated will cause an automatic cut-off. Series 3 will automatically cut off after 120 seconds of use.
 - The green LED perimeter will flash five times before cutting off.
 - To cut off the heating function manually, press and hold the activation button for three seconds.
- * Pack the material inside the cartridge loosely enough to allow room for air to flow. This allows the heated air inside the cartridge to make uniform contact with the material, producing maximum vapor.

Loose Leaf Cartridge Maintenance

Cleaning your cartridge helps to ensure it lives a long, full life. Your loose leaf cartridge comes with the tools needed to perform regular maintenance. Use the pick to remove particles of used loose leaf and the brush to sweep away smaller debris left inside the chamber.

Wax Cartridge

1. Unscrew the base of the cartridge to access the ingredient chamber.
 2. Use the scoop of the included pick tool to add wax* to the cartridge. Do not fill beyond the rim of the cartridge basin.
 3. Screw the cartridge body back onto the base and insert the cartridge into the Series 3 cartridge chamber.
 4. Make sure Series 3 is unlocked.
 5. Press and hold the activation button as you begin puffing.
 - To prevent accidental/undesired activation, Series 3 will automatically cut off if the activation button is held down for 30 consecutive seconds after Series 3 is activated.
 - We recommend holding your Series 3 device vertically when using the wax* cartridge, to ensure the wax* makes consistent contact with the heating coil.
- * This cartridge is also compatible with gels and similar concentrates.